

Section	Compliance with SA Water's Requirements	Remarks
All		The Pressure Sewerage Code of Australia Drawings detail a number of Best Practice options and arrangements. While these are all options, they are not necessarily all suitable for use in South Australian conditions. Where any confusion arises or requirements vary with normal SA Water practices contact SA Water's representative for clarification.
PSS-1000	Complies	Alternatively SA Water's water supply embedment requirements can be used
PSS-1001	Complies	Concrete encasement on to be used with site specific approval from SA Water
PSS -1002	Complies	
PSS -1003	Complies	Encasing pipe not required unless specifically directed by SA Water
PSS -1004	Complies	
PSS -1005	Complies	Plastic Identification Covers (note 3) not required
PSS -1006	Complies	
PSS -1007	Complies	
PSS -1101	Complies	Contact SA Water for local example Site plan and Design Layout
PSS -1101	Complies	
PSS -1102	Complies	
Installation of PE pipe details as shown in Pt 4 of the Water Supply Code of Australia (Drawings Section) may also be used for reference.		