

ISSUED 1ST OCTOBER 2002

<u>SECTION</u>	<u>L</u>	<u>INSPECTION OPENINGS, ACCESS CHAMBERS</u>
PAGE	DRAWING NO.	TITLE
L1	94 - 0167 - 01	General Notes.
L2	94 - 0167 - 02	Access Chamber and Inspection Opening - Locations in Roadways & Easements.
L3	94 - 0167 - 03	DN 150 Inspection Openings.
L4	94 - 0167 - 04	Typical Construction Details for 900 Internal Diameter Access Chamber.
L5	94 - 0167 - 05A	Typical Construction Details for 1050 Internal Diameter Access Chamber.
L6	94 - 0167 - 06A	Typical Construction Details for 1200 Internal Diameter Access Chamber.
L7	94 - 0167 - 07	Typical Construction Details for 1400 ID Insitu Access Chamber with Conical Top.
L8	94 - 0167 - 08	Typical Construction Details for 1500 Internal Diameter 'Control' Access Chamber.
L9	94 - 0167 - 09	Bench and Channel Details in Access Chambers for Sewers up to DN 600.
L10	94 - 0167 - 10	Channel Configurations in Access Chambers for Sewers up to DN 600 and Access Chamber With Temporary End.
L11	94 - 0167 - 11	Access Chamber with DN 150 UPVC External Jump Up.
L12	94 - 0167 - 12	Access Chamber with DN 150 UPVC Internal Sewer Jump Up.
L13	94 - 0167 - 13	Trunk Sewer Access Chamber for DN 675 and 750 Sewers.
L13A	99 - 0114 - 01	Trunk Sewer MH for DN 450 and Larger Sewers Utilising "Lost" Formwork".
L13B	94 - 0115 - 01	Trunk Sewer MH for DN 450 and Larger Sewers Straight Through Only
L14	94 - 0167 - 14	Typical Construction Details for Lightweight Access Chamber for use in Easements with Restricted Access.
L15	94 - 0167-15	Height and Crossfall Adjustment Details for Access Chamber Cover Slabs
L16	02 – 0289 - 01	Maintenance Shafts Typical Installation
L17	02 – 0290 - 01	Maintenance Shafts with Variable Bends
L18	02 – 0291 – 01A	Maintenance Shaft Terminal and End Maintenance Shaft with Connections Ahead