

QUICK REFERENCE GUIDE

ISSUED 6th JANUARY 1997

	Section / Page		Section / Page
J			S
Jump-Up			Shoring
access chamber	L10,11		Specifications
connection	K6,10		Step-Benched Trench
			Switchboard Cubicle
M			
Maintenance Hole (See Access Chamber)			T
Maintenance Shaft	M16-M18		Telemetry cables (pumping stations)
			Traffic
			control
P			diversion
Pipelaying			Trenchfill
pumping main discharge into access chamber	H2		Trenching
railway crossings	H3		
water seal branch	H1		U
Pumping Mains			Underground Services
Air Relief Valves	M18		
Indicator Posts and Signs	M19		
In-line Stop Valve Assembly	M16		V
Pump-out Branch	M17		Valve Chambers
Pumping Stations			lids
access	M10		location
electrical cubicle	M6		pipework
ETSA service	M7		
fence detail	M8		Vents
plan and section	M5		induct
site arrangement	M1,3,4		educt
standard notes	M2		siting
telemetry	M7		
			W
R			Water Seal (connections)
Railway Crossing (Pipelaying)	H3		Water Seal (branch sewers)
References	E		Water Service (Pumping Stations)
Regulations	E		

F3
E
G5,6,
M1,3,4

M7

D2
D1
G
G

C

M13
M5
M13

J2
J3
J

K11
H2
M11