

ISSUED 6th JANUARY 1997

| <u>SECTION</u> | <u>M</u>           | <u>STANDARD SUBMERSIBLE SEWERAGE PUMPING STATIONS</u>  |
|----------------|--------------------|--|
| <u>PAGE</u>    | <u>DRAWING NO.</u> | <u>TITLE</u>   |
| M1             | 94 - 0163 - 01     | Site Arrangement   |
| M2             | 94 - 0163 - 02     | Standard Notes - Sheet 1.  |
| M3             | 94 - 0163 - 03     | Standard Notes - Sheet 2.  |
| M4             | 94 - 0163 - 04     | Standard Notes - Sheet 3.  |
| M5             | 94 - 0163 - 05     | Site Arrangement and Access Where Station Abuts a Public Road.                                 |
| M6             | 94 - 0163 - 06     | Site Arrangement and Access Road Where Station Does Not Abut a Public Road.                    |
| M7             | 94 - 0163 - 07     | Plan and Section.  |
| M8             | 94 - 0163 - 08     | Electrical Cubicle, Base and Conduit Details.  |
| M9             | 94 - 0163 - 09     | ETSA Service and Telemetry Details Including Embedment and Trenchfill for Electrical Conduits. |
| M10            | 94 - 0163 - 10     | Fence Detail (Typical).  |
| M11            | 94 - 0163 - 11     | DN 40 Water Service  |
| M12            | 94 - 0163 - 12     | Access Roadway, Cross Section and Drainage Details (Typical).                                  |
| M13            | 94 - 0163 - 13     | Typical Arrangement for Valve Chamber (Non-Trafficable).                                       |
| M14            | 94 - 0163 - 14     | Typical Arrangement for Valve Chamber With Flow Meter (Non-Trafficable).                       |
| M15            |                    | To be Issued   |
| M16            | 94 - 0163 - 16     | In-Line Stop Valve Assembly for DN 100 to DN 200 Sewage Pumping Mains                          |
| M17            | 94 - 0163 - 17     | Pump-out Branch for Sewage Pumping Mains   |
| M18            | 94 - 0163 - 18     | Air Relief Valves for Sewage Pumping Mains   |
| M19            | 94 - 0163 - 19     | Indicator Post and Signs for Sewage Pumping Mains  |

**THIS SECTION IS UNDER REVIEW  
CONTACT PRINCIPAL ENGINEER WASTE WATER NETWORKS ON (08) 8463 6037 BEFORE SPECIFYING ANY SPS**